
Plumbed-in Original

Leaking




For Sales, Filters, Service & Repairs PH: 0401 441 291 f www.awesomewatermackay.com info@awesomewatermackay.com






Remove 2x screws at the back to take the cover off



Check the feeder pipe going into the tank – see next page



Push back the clip as displayed



Pull the pipe to release



Push the pipe back as far as possible, and pull back on pipe to make sure it is locked in


Fitting the pipes securely



Remove the plug that sits in the tank by lifting it at one side, pulling upwards. Be careful as the edges of the tank is very sharp.




If the water is all the way to the top, drain some water by running the tap, until about half full.



Tap the float a few times to make sure it isn't stuck.



Clean plug and float by wiping it down with a clean chux, under some running water to remove any residue built up



When returning the plug, make sure the seal is in place. Push down slowly on all sides of the plug until it fits tightly into the tank.

Return plug & secure feeder pipe (page 4). Turn water supply back on and check for any leaks after about 10 mintues.

If leaking still persist, a technician will have to inspect, float might need to be replaced.



Book Appointment